

Cleaning & Care Guide

General remarks

Congratulations on choosing your COREPEL flooring, the newest flooring innovation from Swiss Krono Group. You have made the right decision for an eco-friendly, low maintenance, robust, and hard-wearing floor covering with a long life and easy-to-clean surface.

Just a little time and effort can go a long way to ensuring that your new COREPEL floor stays in beautiful condition.

A room temperature of 18-25 °C (64-77 °F) with relative humidity of 50-70 % ensures a feeling of well-being and a healthy, pleasant environment in the room.

Prevention is best

We all know that most dirt is brought into the home from outside and then is trodden into the floor. The best cleaning method is to keep the dirt out altogether. Leave it outside the door by simply putting a full-sized doormat down at your front door. Damage resulting from improper care and maintenance of the floor is not covered by the warranty.

Do not leave any spilled liquids (water, juice, pet urine, etc.) to dry on the floor. Clean any wet spots immediately. Avoid excessive exposure to water at main entrances during periods of inclement weather.

But remember: dirt carried in on footwear can cause damage to all floor coverings. Gravel and dirt can act like sandpaper and cause unsightly scratches. Chair legs, table legs, and cupboard feet should be fitted with felt pads – it's easier to move them and prevents scratches.

And another tip: don't forget to fit office chairs, filing trolleys, and mobile containers with soft treads or castors - these are recognizable by their two-tone construction. Old hard or sharp-edged castors on existing furniture should also be replaced.



Cleaning of COREPEL

Remove any dust, and dirt with a broom or vacuum cleaner suitable for hard surfaces.

A thorough cleaning is then recommended to get rid of any dirt residues which might linger. COREPEL can be cleaned with a wet mop, battery powered jet mop (such as Swiffer Wet Jet) or (residential) steam cleaner.

If using a traditional mop, use a suitable "hard surface" cleaner (for example KRONOSWISS CLEANER) diluted in water. Do not use any cleaning agents containing wax, oil or polish, which can form a dull film that will reduce the appearance and performance of your COREPEL floor.

Cleaning of stubborn stains on COREPEL

An alcohol-based cleaner can be used for difficult stains but should be applied to a cleaning cloth and not directly on the floor, and the affected area should be cleaned afterwards with water.

Please note: do not use abrasive cleaning pads, sponges and cloths, or scourers, etc. Do not sand, varnish or wax your COREPEL floor.

Following these simple instructions will ensure that your COREPEL floor remains beautiful for a lifetime!